

# 目 录


## CONTENTS

| No. | Description                                   | Page |
|-----|---|------|
| 1.1 | 工作装置总成.....wroking device assembly            | P1   |
| 1.2 | 挖斗.....excavator                              | P2   |
| 1.3 | 挖斗油缸总成..... bucket cylinder assembly          | P3   |
| 1.4 | 斗杆油缸总成.....bucket rpd cylinder assembly       | P4   |
| 1.5 | 动臂油缸总成.....arm cylinder assembly.             | P5   |
| 2.1 | 上盘外观总成.....the appearance of the discassembly | p6   |
| 3.1 | 上盘内部总成.....the internal assembly plater       | p7   |
| 3.2 | 动力总成..... Power assembly                      | p8   |
| 3.3 | 新左扶手箱总成.....Left armrest case assembly        | p9   |
| 3.4 | 新右扶手箱总成.....right armrest case assembly       | p10  |
| 3.5 | 油箱总成.....oil tank assembly                    | p11  |
| 3.6 | 座椅支架总成.....Seat bracket assembly              | P12  |
| 3.7 | 铰接总成.....Aeticulated assembly                 | p13  |


|                   |                                       |     |
|-------------------|---------------------------------------|-----|
| 3.8 偏摆油缸总成.....   | Side sway cylinder assembly           | p14 |
| 4.1 伸缩下盘总成.....   | Telescopic lower assembly             | p15 |
| 4.2 推土铲总成.....    | cylinder assembly                     | P16 |
| 1.6 推土铲油缸总成.....  | Bulldozer cylinder assembly           | P17 |
| 1.8 伸缩油缸总成.....   | Telescopic cylinder assembly          | p18 |
| 5. 挖掘机包络图.....    | Excavator envelope diagram            | P19 |
| 6.1 挖斗（辅具） .....  | Bucket (auxiliary equipment)          | p20 |
| 6.2 泥浆斗（辅具） ..... | Mud hopper (auxiliary equipment)      | p21 |
| 6.3 倾斜斗（辅具） ..... | Lnclined bucket (auxiliary equipemnt) | p22 |
| 6.4 耙子（辅具） .....  | Rake (auxiliary equipemnt)            | p23 |
| 6.5 旋挖钻（辅具） ..... | Rotary drilling (auxiliary equipemnt) | p24 |
| .6.6 快换（辅具） ..... | Change quickly (auxiliary equipemnt)  | p25 |
| 6.7 抓木器（辅具） ..... | Wood gripper (auxiliary equipemnt)    | p26 |

## 1.1 工作装置总成

| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/ITY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-------------|---------------|
| 1             | LP0107021140    | 动臂支架连动臂销轴       | 1           |               |
| 2             | LP0107021138    | 动臂支架连动臂油缸销轴     | 1           |               |
| 3             | LP0115010061    | 动臂油缸总成          | 1           |               |
| 4             | LP0107020092    | 30×99 销轴        | 1           |               |
| 5             | LP0107020096    | 斗杆油缸销轴          | 1           |               |
| 6             | LP0115010062    | 斗杆油缸总成          | 1           |               |
| 7             | LP0107020097    | 斗杆耳板销轴          | 1           |               |
| 8             | LP0107021132    | 动臂连斗杆销轴         | 1           |               |
| 9             | LP0107020097    | 斗杆耳板销轴          | 1           |               |
| 10            | LP0115010063    | 铲斗油缸总成          | 1           |               |
| 11            | LP0112011037    | 斗杆              | 1           |               |
| 12            | LP0112012556    | 摇杆（带孔）          | 1           |               |
| 13            | LP0112013284    | 摇杆（不带孔）         | 1           |               |
| 14            | LP0107021005    | 319N 摇杆固定轴      | 1           |               |
| 15            | LP0107050036    | 319N 摇杆固定轴（黄油嘴） | 1           |               |
| 16            | LP0112012555    | 铸造连杆            | 1           |               |
| 17            | LP0107021006    | 挖斗销轴            | 2           |               |
| 18            | LP0104011028    | 400mm 挖斗        | 1           |               |
| 19            | LP0106020232    | 大灯              | 1           |               |
| 20            | LP0112013016    | 动臂              | 1           |               |
| 21            | LP0115021277    | 三通球阀总成          | 2           |               |




## 1.2 挖斗总成




| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/TY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|------------|---------------|
| 1             | LP0104011028    | 挖斗总成            | 1          |               |
| 2             | LP011109078     | 侧齿              | 2          |               |
| 3             | LP0111080032    | 正齿              | 3          |               |

### 1.3 挖斗油缸总成




| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>QTY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-----------|---------------|
|               | LP0115010063    | 铲斗油缸总成          | 1         |               |
| 1             | LP0115010168    | 铲斗油缸缸体          | 1         |               |
| 2             | LP0115010169    | 铲斗油缸缸杆          | 1         |               |
| 3             | LP0116031360    | 铲斗活塞环组          | 1         |               |
| 4             | LP0116010092    | 黄油嘴 MI0*1       | 2         |               |

## 1.4 斗杆油缸总成



| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/ITY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-------------|---------------|
|               | LP0115010062    | 斗杆油缸总成          | 1           |               |
| 1             | LP0115010166    | 斗杆油缸缸体          | 1           |               |
| 2             | LP0115010167    | 斗杆油缸缸杆          | 1           |               |
| 3             | LP0116031359    | 斗杆活塞环组          | 1           |               |
| 4             | LP0116010092    | 黄油口 M10*1       | 2           |               |


## 1.5 动臂油缸总成



| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>QTY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-----------|---------------|
|               | LP0115010061    | 动臂油缸总成          | 1         |               |
| 1             | LP0115010164    | 动臂油缸缸体          | 1         |               |
| 2             | LP0115010165    | 动臂油缸缸杆          | 1         |               |
| 3             | LP0116031358    | 动臂活塞密封圈         | 1         |               |
| 4             | LP0116010092    | 黄油口 M10*1       | 2         |               |


## 2.1 上盘外观总成

| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/TY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|------------|---------------|
| 1             | LP0112011948    | 配重喷塑            | 1          |               |
| 2             | LP0112012363    | 先导座椅盖板喷塑        | 1          |               |
| 3             | LP0112012337    | 先导脚踏板喷塑         | 2          |               |
| 4             | LP0112012129    | 左上护罩喷塑          | 1          |               |
| 5             | LP0112012117    | 左下护罩喷塑          | 1          |               |
| 6             | LP0112010272    | 座椅铰接喷塑          | 1          |               |
| 7             | LP0112012494    | 座椅固定板喷塑         | 1          |               |
| 8             | LP0112012493    | 座椅安装板喷塑         | 1          |               |
| 9             | LP0108040007    | 座椅              | 1          |               |
| 10            | LP0112011954    | 护罩侧板喷塑          | 1          |               |
| 11            | LP0112012360    | 右上护罩喷塑          | 2          |               |
| 12            | LP0108020052    | NDI 顶棚总成        | 1          |               |
| 13            | LP0108020002    | 顶棚盖             | 1          |               |
| 14            | LP0112012119    | 右下护罩喷塑          | 1          |               |
| 15            | LP0112010649    | 后护罩喷塑           | 1          |               |




### 3.1 上盘内部总成

| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/TY | 备注<br>REMA<br>RKS |
|---------------|-----------------|-----------------|------------|-------------------|
| 1             | LP0107021131    | 动臂支架销轴          | 1          |                   |
| 2             | LP0107021130    | 偏摆油缸前叉销轴        | 1          |                   |
| 3             | LP0115010078    | 偏转油缸            | 1          |                   |
| 4             | LP0102030001    | 回转马达            | 1          |                   |
| 5             | LP0115040010    | 塑料柴油箱           | 1          |                   |
| 6             | LP0112012072    | 右下护罩安装板         | 1          |                   |
| 7             | LP0115041173    | 塑料液压油箱          | 1          |                   |
| 8             |                 | 保护器             | 1          |                   |
| 9             |                 | 整流器             | 1          |                   |
| 10            |                 | 座椅支架总成          | 1          |                   |
| 11            |                 | 保险盒安装板          | 1          |                   |
| 12            | LP0115030049    | 先导过滤器           | 1          |                   |
| 13            |                 | 保险盒             | 1          |                   |
| 14            | LP0119020187    | 发动机总成           | 1          |                   |
| 15            | LP0115030028    | 伸缩电磁阀切换阀        | 1          |                   |
| 16            | LP0106010004    | 蓄电池             | 1          |                   |
| 17            | LP0107010248    | 铰接总成            | 1          |                   |
| 18            | LP0112012309    | 左下护罩安装板         | 1          |                   |
| 19            | LP0112013924    | 上盘喷塑            | 1          |                   |
| 20            | LP0112013016    | 动臂支架            | 1          |                   |
| 21            | LP0116030392    | 继电器             | 4          |                   |




### 3.2 动力总成

| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>QTY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-----------|---------------|
| 1             | LP0103020003    | 久保田 D722 发动机    | 1         |               |
| 2             |                 | 发动机安装板 1        | 1         |               |
| 3             | LP0111020035    | 发动机减震垫          | 4         |               |
| 4             | LP0110020012    | 散热器             | 1         |               |
| 5             | LP0113010022    | 整套橡胶软管          | 1         |               |
| 6             | LP0114010056    | 消音器             | 1         |               |
| 7             | LP0101010025    | 齿轮泵             | 1         |               |
| 8             | LP0102010037    | 飞轮壳             | 1         |               |
| 9             | LP0102010038    | 联轴器             | 1         |               |
| 10            |                 | 发动机安装板 2        | 1         |               |




### 3.3 新左扶手箱总成




| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/TY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|------------|---------------|
| 1             | LP0106040042    | 翘板开关            | 1          |               |
| 2             | LP0111030063    | 左扶手箱            | 1          |               |
| 3             | LP0115030005    | 先导左手柄           | 1          |               |
| 4             | LP0116030472    | 小号扶手托           | 1          |               |

### 3.4 新右扶手箱总成

| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/TY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|------------|---------------|
| 1             | LP0115030006    | 右侧先导手柄          | 1          |               |
| 2             | LP0111030064    | 右侧扶手箱           | 1          |               |
| 3             | LP0106040043    | 仪表              | 1          |               |
| 4             | LP0115030011    | 推土手柄            | 1          |               |
| 5             | LP0116030472    | 小号扶手托           | 1          |               |




### 3.5 油箱总成




| 序号<br>REF NO. | 部品号<br>Part No. | 名称<br>Part Name | 数量<br>Q/TY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|------------|---------------|
|               | LP0115040077    | NDI 油箱总成        | 1          |               |
| 1             | LP0115040010    | 塑料柴油箱           | 1          |               |
| 2             | LP0111040007    | 油位传感器           | 1          |               |
| 3             | LP0107021028    | 油位传感器座          | 1          |               |
| 4             | LP0111080091    | 柴油箱盖            | 1          |               |
| 5             | LP0112010264    | 油箱固定板           | 1          |               |
| 6             | LP0111080091    | 液压油箱盖           | 1          |               |
| 7             | LP0115030046    | 液压回油过滤器         | 1          |               |
| 8             | LP0115040073    | 塑料液压油箱          | 1          |               |
| 9             | LP0112012646    | 液压油箱安装板         | 1          |               |

### 3.6 座椅支架总成




| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/ITY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-------------|---------------|
| 1             | LP0112013101    | 座椅铰接板喷塑         | 1           |               |
| 2             |                 | 柴油元件安装板         | 1           |               |
| 3             | LP0111020081    | 电子打油泵           | 1           |               |
| 4             | LP0112013093    | 油箱护板喷塑          | 1           |               |
| 5             | LP0113010214    | 发动机进气管          | 1           |               |
| 6             | LP0111030064    | 右扶手箱总成          | 1           |               |
| 7             | LP0111020090    | 柴油滤芯            | 1           |               |
| 8             | LP0111010005    | 空气滤芯            | 1           |               |
| 9             | LP0106040054    | 电源总开关           | 1           |               |
| 10            | LP0113010217    | 空滤进气管           | 1           |               |
| 11            |                 | 久保田先导滤芯安装板      | 1           |               |
| 12            | LP0111020082    | 粗滤              | 1           |               |
| 13            | LP0111030049    | 先导滤芯            | 1           |               |
| 14            |                 | 副水壶固定卡          | 1           |               |
| 15            | LP0111030063    | 左扶手箱总成          | 1           |               |
| 16            | LP0111080035    | 副水壶             | 1           |               |
| 17            | LP0111020089    | 久保田油水分离器        | 1           |               |
| 18            | LP0112013922    | 座椅支架            | 1           |               |

### 3.7 铰接总成




| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>QTY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-----------|---------------|
| 1             | LP0101030025    | 多路阀             | 1         |               |
| 2             | LP0116011159    | 正丝球头            | 4         |               |
| 3             | LP0116011160    | 反丝球头            | 4         |               |
| 4             | LP0111080081    | 脚踏板             | 2         |               |
| 5             | LP0111080202    | 把手护套            | 2         |               |
| 6             | LP0107010248    | 322 整套铰接        | 1         |               |
| 7             | LP0112012339    | 多路阀安装板          | 1         |               |

## 1.8 偏转油缸总成



| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/TY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|------------|---------------|
| 1             | LP0115010155    | 偏转油缸缸体          | 1          |               |
| 2             | LP0116030609    | 整套偏转油缸油封        | 1          |               |
| 3             | LP0115010156    | 偏转油缸缸杆          | 1          |               |


#### 4.1 伸缩下盘总成




| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/ITY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-------------|---------------|
| 1             | LP0115010086    | 伸缩油缸            | 1           |               |
| 2             | LP011109555     | 左侧行走支架          | 1           |               |
| 3             | LP0116012356    | 限位螺栓            | 2           |               |
| 4             | LP0102090005    | 驱动齿轮            | 2           |               |
| 5             | LP0102020023    | 行走马达            | 2           |               |
| 6             | LP0102110002    | 橡胶履带            | 2           |               |
| 7             | LP0102070016    | 涨紧杆             | 2           |               |
| 8             | LP0102070002    | 机械张紧装置          | 1           |               |
| 9             | LP0115010060    | 推土油缸            | 1           |               |
| 10            | LP0112012652    | 推土铲总成           | 1           |               |
| 11            | LP0102050002    | 中央回转接头          | 1           |               |
| 12            | LP0102040001    | 中央回转支撑          | 1           |               |
| 13            | LP0102060001    | 支重轮             | 4           |               |
| 14            | LP011109556     | 右侧行走支架          | 1           |               |
| 15            | LP0112013098    | 黄油嘴盖板           | 2           |               |
| 16            | LP0112013783    | 下盘支架            | 1           |               |

## 4.2 推土铲总成

| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q'TY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|------------|---------------|
| 1             | LP0112012653    | 推土铲左侧加宽耳板       | 1          |               |
| 2             | LP0112012652    | 推土铲             | 1          |               |
| 3             | LP0112012654    | 推土铲右侧加宽耳板       | 1          |               |
| 4             | LP0107020095    | 25X70 销轴        | 2          |               |
| 5             | LP0107020094    | 25X80 销轴        | 2          |               |




### 4.3 推土铲油缸总成




| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>QTY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-----------|---------------|
|               | LP0115010082    | 推土铲油缸           | 1         |               |
| 1             | LP0115010151    | 推土铲油缸缸体         | 1         |               |
| 2             | LP0112010831    | 推土铲油缸护板吸塑       | 1         |               |
| 3             | LP0112010831    | 推土铲油缸缸杆         | 1         |               |
| 4             | LP0116030607    | 整套推土铲油缸油封       | 1         |               |

#### 4.4 伸缩油缸总成




| 序号<br>REF NO. | 部品号<br>Part NO. | 名称<br>Part Name | 数量<br>Q/ITY | 备注<br>REMARKS |
|---------------|-----------------|-----------------|-------------|---------------|
|               | LP0115010083    | 伸缩油缸            | 1           |               |
| 1             | LP0115010153    | 伸缩油缸缸体          | 1           |               |
| 2             | LP0116030608    | 整套伸缩油缸油封        | 1           |               |
| 3             | LP0115010154    | 伸缩油缸缸杆          | 1           |               |

## 5. R15-3 (XD-JBT) 包络图



## 6. R15-3 辅具（安装尺寸：轴径 25、档距 92、轴间距 90）

### 6.1 R15-3 挖斗




| 序号<br>REF No. | 挖斗宽度<br>Size. | 部品号<br>Part No. | 名称<br>Part Name |
|---------------|---------------|-----------------|-----------------|
| 1             | L=200mm       | LP0104010778    | 200 挖斗          |
| 2             | L=300mm       | LP0104010928    | 300 挖斗          |
| 3             | L=400mm       | LP0104010980    | 400 挖斗          |
| 4             | L=500mm       | LP0104010774    | 500 挖斗          |
| 5             | L=600mm       | LP0104010775    | 600 挖斗          |
| 6             | L=800mm       | LP0104010781    | 800 挖斗          |
| 7             | L=1000mm      | LP0104010782    | 1000 挖斗         |

|              |       |   |
|--------------|-------|---|
| LP0107021006 | 挖斗固定轴 | 2 |
|--------------|-------|---|

安装尺寸见 6.1 挖斗

## 6.2 R15-3 泥浆斗




| 序号<br>REF No. | 尺寸<br>Size. | 部品号<br>Part No. | 名称<br>Part Name |
|---------------|-------------|-----------------|-----------------|
| 1             | L=250mm     | LP0104010814    | 250 泥浆斗 (打坡口)   |
| 2             | L=300mm     | LP0104010808    | 300 泥浆斗 (打坡口)   |
| 3             | L=400mm     | LP0104010802    | 400 泥浆斗 (打坡口)   |
| 4             | L=500mm     | LP0104010809    | 600 泥浆斗 (打坡口)   |
| 5             | L=600mm     | LP0104010810    | 750 泥浆斗 (打坡口)   |
| 6             | L=800mm     | LP0104010811    | 800 泥浆斗 (打坡口)   |
| 7             | L=1000mm    | LP0104010812    | 1000 泥浆斗 (打坡口)  |

安装尺寸见 6.1 挖斗

|              |       |   |
|--------------|-------|---|
| LP0107021006 | 挖斗固定轴 | 2 |
|--------------|-------|---|

### 6.3 R15-3 倾斜斗


| 序号<br>REF No. | 尺寸<br>Size. | 油缸数量<br>Number of<br>cylinders | 部品号<br>Part No. | 名称<br>Part Name  |
|---------------|-------------|--------------------------------|-----------------|------------------|
| 1             | L=600mm     | 1                              | LP0104010796    | 600 单油缸倾斜斗（打坡口）  |
| 2             | L=800mm     | 1                              | LP0104010797    | 800 单油缸倾斜斗（打坡口）  |
| 3             | L=1000mm    | 1                              | LP0104010798    | 1000 单油缸倾斜斗（打坡口） |
| 4             | L=800mm     | 2                              | LP0104010799    | 800 双油缸倾斜斗（打坡口）  |



|              |       |   |
|--------------|-------|---|
| LP0107021006 | 挖斗固定轴 | 2 |
|--------------|-------|---|

安装尺寸见 6.1 挖斗

## 6.4 R15-3 耙子




| 序号<br>REF No. | 尺寸<br>Size. | 部品号<br>Part No. | 名称<br>Part Name |
|---------------|-------------|-----------------|-----------------|
| 1             | L=400mm     | LP0104010784    | 400 耙子          |
| 2             | L=500mm     | LP0104010785    | 500 耙子          |
| 3             | L=600mm     | LP0104010786    | 600 耙子          |
| 4             | L=800mm     | LP0104010787    | 800 耙子          |
| 5             | L=1000mm    | LP0104010788    | 1000 耙子         |

安装尺寸见 6.1 挖斗

|              |       |   |
|--------------|-------|---|
| LP0107021006 | 挖斗固定轴 | 2 |
|--------------|-------|---|

## 6.5 R15-3 旋挖钻



| 序号<br>REF No. | 长度<br>Length. | 直径<br>Diameter | 部品号<br>Part No. | 名称<br>Part Name       |
|---------------|---------------|----------------|-----------------|-----------------------|
| 1             | L=800mm       | D=φ15mm        | LP0104010048    | 80cm 长直径 15cm 旋挖钻     |
| 2             | L=800mm       | D=φ20mm        | LP0104010053    | 80cm 长直径 20cm 旋挖钻     |
| 3             | L=800mm       | D=φ30mm        | LP0104010058    | 80cm 长直径 30cm 旋挖钻     |
| 4             | L=800mm       | D=φ40mm        | LP0104010063    | 80cm 长直径 40cm 旋挖钻     |
| 5             | L=1000mm      | D=φ20mm        | LP0104010182    | 100cm 长直径 30cm 旋挖钻    |
| 6             | L=1000mm      | D=φ25mm        | LP0104010711    | 100cm 长直径 25cm 旋挖钻    |
| 7             | L=1000mm      | D=φ30mm        | LP0104010190    | 100cm 长直径 30cm 旋挖钻    |
| 8             | L=1200mm      | D=φ15mm        | LP0104011145    | 120cm 长直径 15cm 减速机旋挖钻 |
| 9             | L=1200mm      | D=φ20mm        | LP0104010156    | 120cm 长直径 20cm 旋挖钻    |
| 10            | L=1500mm      | D=φ10mm        | LP0104010088    | 150cm 长直径 10cm 减速机旋挖钻 |
| 11            | L=1500mm      | D=φ20mm        | LP0104011091    | 150cm 长直径 20cm 减速机旋挖钻 |

|              |       |   |
|--------------|-------|---|
| LP0107021006 | 挖斗固定轴 | 2 |
|--------------|-------|---|

安装尺寸见 6.1 挖斗

## 6.6 R15-3 快换




图 6.6.1 液压快换





图 6.6.2 机械快换

| 序号<br>REF No. | 部品号<br>Part No. | 名称<br>Part Name |
|---------------|-----------------|-----------------|
| 1             | LP0104010770    | 先导液压快换          |
| 2             | LP0104010233    | 机械快换            |

|              |       |   |
|--------------|-------|---|
| LP0107021006 | 挖斗固定轴 | 2 |
|--------------|-------|---|

## 6.7 R15-3 抓木器



| 序号<br>REF No. | 部品号<br>Part No. | 名称<br>Part Name |
|---------------|-----------------|-----------------|
| 1             | LP0104010837    | 轻型抓木器二板         |
| 2             | LP0104010477    | 液压旋转抓木器         |

|              |       |   |
|--------------|-------|---|
| LP0107021006 | 挖斗固定轴 | 2 |
|--------------|-------|---|