


CONTENTS


No.	Description	Page
1、	RS 07 Vehicle explosion pattern	2
2、	RS 07 Working device	3
3、	RS 07 Frame	5
4、	RS 07 Engine	8
5、	RS 07 Cockpit	10
6、	RS 07 Body walking device	12
7、	RS 07 Bucket cylinder	13
8、	RS 07 Boom cylinder	14
9、	RS 07 Envelope diagram	15

1、 Vehicle explosion pattern




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0112014145	Working equipment	1	
2	LP0601040020	Track	2	
3	LP0102020026	Drive motor	2	
4	LP0102090013	Drive sprocket	2	
4	LP0115010178	Boom cylinder	2	
5	LP0605010167	Upper arm cylinder support	2	
6	LP0107020143	Front pin of boom cylinder	2	
7	LP0107020142	Rear pin of boom cylinder	2	
8	LP0107020141	Rear seat pin of boom	2	
9	LP0108010202	Cab	1	
10	LP0103020006	Engine assembly	1	
11	LP0106010005	Battery	1	

1、 Vehicle explosion pattern




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0112014145	Working equipment	1	
2	LP0115010178	Boom cylinder	2	
3	LP0605010167	Upper arm cylinder support	1	
4	LP0107020143	Front pin of boom cylinder	2	
5	LP0102020022	Front tire motor	2	
6	LP011109562	Flange plate	4	
7	LP011109550	Right tire	4	
8	LP0102020021	Rear tire motor	2	
9	LP0107020142	Rear pin of boom cylinder	2	
10	LP0107020141	Rear seat pin of boom	2	
11	LP0108010202	Cab	1	
12	LP0106010005	Battery	1	
13	LP0103020006	Engine assembly	1	

2、RS 07 working device




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0104011385	Bucket	1	
2	LP0104011386	Quick-change	1	
3	LP0107020144	Bucket oil cylinder rear pin shaft	2	
4	LP0115010179	Bucket oil cylinder	2	
5	LP0115021220	Diverting block	1	
6	LP0601020107	Two-hole nylon tube clamp	6	
7	LP0602050053	Slide RS07 right side pipe - outside	1	
8	LP0602050054	Slide RS07 right side tube - inside	1	

2、RS 07 working device




REF NO.	Part NO .	Name	Q/TY	REMARKS
9	LP0605010167	Boom cylinder support plate	1	
10	LP0603020107	Boom cylinder front pin axis	2	
11	LP0112014145	Upper arm	1	
12	LP0602050055	Slide RS07 left pipe-inside	1	
13	LP0602050056	Slide RS07 left pipe-outside	1	
14	LP0602050057	Slide RS07 left pipe-outside lower	1	
15	LP0605010178	Auxiliary tool extended wall mounting seat	1	

3、RS 07 Frame




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0101030063	Electromagnetic multi-way valve - M45	1	
2	LP0604020061	Universal horn	1	
3	LP0113040044	Cab shock-absorbing pad	4	
4	LP0605010168	Foot pedal	1	
5	LP0602040017	Telescopic electromagnetic switching valve	1	
6	LP0602040016	Two-hand operation busbar - 8 holes	1	
7	LP0102020026	Travel motor assembly	4	
8	LP0601040053	Sliding RS07 front tire	2	
9	LP0601040054	Sliding RS07 rear tire	2	
10	LP0115030062	Double spool pilot solenoid valve	1	

3、RS 07 Frame




REF NO.	Part NO .	Name	Q/TY	REMARKS
11	LP0115030071	Flushing valve	2	
12	LP0605010175	Double valve support	1	
13	LP0605010179	Cab mounting seat	2	
14	LP0111080503	Oil level sensor	1	
15	LP0111080502	Lockable fuel tank cap	2	
16	LP0112020167	Frame	1	
17	LP0605010169	Rear cover plate	1	
18	LP0601060141	External tail pipe of muffler	1	
19	LP0605010170	Rear door	1	
20	LP0602060012	Hydraulic oil flange	1	

3、RS 07 Frame




REF NO.	Part NO .	Name	Q/TY	REMARKS
21	LP0111050003	Outlet filter element of hydraulic oil	2	
22	LP011109060	Hydraulic oil window M24*1.5	1	
23	LP0111020089	Kubota oil-water separator	1	
24	LP0601010098	Kubota fuel filter	1	
25	LP0109011392	Kubota electronic pump	2	
26	LP0605010176	Diesel filter bracket	1	
27	LP0113040016	Rubber strip hose clamp	1	
28	LP0111020082	Kubota coarse filter	1	
29	LP0115030046	Straight return hydraulic return oil	1	
30	LP0106040054	Main power switch	1	
31	LP0601010036	Pedal springs	2	
32	LP0601010066	Gas pedal	1	

4、RS 07 Engine




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0101010010	316 gear pump	1	
2	LP0101020010	Double plunger pump	1	
3	LP0102010078	D1105 flywheel disc	1	
4	LP0114010186	Muffler	1	
5	LP0102010079	Coupling	1	
6	LP0103020006	Engine	1	
7	LP0605010171	Muffler fixing plate	1	
8	LP0110020115	Radiator assembly	1	

4、RS 07 Engine




REF NO.	Part NO .	Name	Q/TY	REMARKS
9	LP0601020110	Upper water pipe	1	
10	LP0111010003	Elbow air filter	1	
11	LP0601020111	Lower water pipe	1	
12	LP0111010003	Air filter hose	1	
13	LP0605010172	Throttle cable fixing plate	1	
14	LP0111020042	Shock-absorbing pad	10	
15	LP0605010173	Engine front support plate	2	
16	LP0605010174	Pump support plate	1	

5、RS 07 Cockpit




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0106040062	Electrical Box	1	
2	LP0106040043	Cab Round Light	3	
3	LP0604020067	Cab Warning Light	1	
4	LP0108040021	Agricultural Machinery Seat	1	
5	LP0108010202	Cab Frame	1	
6	LP011109549	Armrest Bracket	2	
7	LP0605010182	Armrest Mounting Bracket	2	
8	LP0111060018	Knob Throttle Cable	1	

5、RS 07 Cockpit




REF NO.	Part NO .	Name	Q/TY	REMARKS
9	LP0115030010	Multi-Button Pilot Handle - Right	1	
10	LP0106020195	Buzzer	1	
11	LP0106020296	Kubota Key Switch	1	
12	LP0605010181	Instrument Mounting Plate	1	
13	LP0106020235	Rocker	1	
14	LP0605010183	Cab Armrest	1	
15	LP0106040043	Instrument / Gauge	1	
16	LP0115030009	Multi-Button Pilot Handle - Left	1	

6、RS 07 Body walking device




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0102070008	Front guide wheel	2	
2	LP0605010021	Sliding X-frame	2	
3	LP0601040020	Caterpillar track	2	
4	LP0102020026	Travel motor	2	
5	LP0102090013	Drive sprocket assembly	2	
6	LP0102060001	Caterpillar track support wheel	6	
7	LP0601040022	Rear guide wheel	2	

7、RS 07 Bucket cylinder




REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0115010179	Bucket cylinder of RS07	1	
2	LP0116012493	Flat-head grease port	2	
3	LP0601020112	Sealing ring of the whole set of cylinder	1	

8、RS 07 Boom cylinder



REF NO.	Part NO .	Name	Q/TY	REMARKS
1	LP0115010178	Boom cylinder of RS07	1	
2	LP0116012493	Flat-head grease port	2	
3	LP0601020113	Sealing ring of the whole set of cylinder	1	

9、RS 07 Envelope diagram



9、RS 07 Envelope diagram

